

SUBJECT:
FLUORESCENT HIGHBAY
"FHB" SERIES

 Day-Brite Lighting
INSTRUCTION SHEET


WARNING: ELECTRICAL SHOCK POTENTIAL !! DO NOT ATTEMPT TO INSTALL, MAINTAIN OR RELAMP WITHOUT DIS-CONNECTING ALL POWER. FAILURE TO DISCONNECT POWER CAN RESULT IN ELECTROCUTION, SHOCK OR SEVERE BURNS.

CAUTION: This fixture is designed for permanent installation in ordinary (Non-Hazardous) locations in accordance with the National Electrical Code and all applicable local codes. Do not use in areas of limited ventilation or in high ambient enclosures. The lamp and fixture operate at high temperatures, contact with combustible materials can cause fire and personal contact can cause severe burns.
NOTE: THERE MUST BE A MINIMUM CLEARANCE OF 6" BETWEEN TOP OF FIXTURE AND SOLID MOUNTING SURFACE.

1. Remove seal from carton and inspect to insure no shipping damage has occurred.
2. This fixture is supplied with a cord and plug and is completely wired and ready for installation.
3. To install remove the V-Hook and chains from the bag pack supplied with the fixture. Hook the V-Hooks into each end of the fixture in the holes located at each end. The chains should then be attached to the permanent structure of the building.

4. If access to the ballast is required remove hump and remove the wiring compartment cover by loosening the quarter turn fasteners located at each end of the fixture. (See Diagram at right)


5. When installation is complete fixture is equipped with a cord and plug (20 or 277V) which should be plugged into a suitable female receptacle located near the fixture @ cord standard.



Quarter turn fastener

Wiring Compartment Cover
Lamp

Chain to support structure above



PERSPECTIVE